

Installation and Operating Instructions

Compact controller series HT40

HT41 / HT42 / HT43 / HT44 / HT45 ...

Contents

1. **Safety**
 - 1.1. Intended usage
 - 1.2. Non Intended usage
 - 1.3. Operator
 - 1.4. Safety - relevant notices
 - 1.5. Liability exclusion
2. **General**
 - 2.1. Unpacking and inspecting
 - 2.2. Standards and regulations
3. **Important reference before start up procedure**
4. **Introduction**
5. **Start up**
 - 5.1 Assembly
 - 5.2 Electrical terminal
 - 5.3 Terminal diagram
 - 5.4 Operation elements and displays
6. **Unit Configuration**
 - 6.1 Configuration tablet
 - 6.2 Controller selection
 - 6.3 Inputs
 - 6.4 Outputs
 - 6.5 Set points
 - 6.6 Adjustment of the display
 - 6.7 Protection against trespassed operation
 - 6.8 Serial interface (Option)
7. **Parameter level**
8. **Controller handling**
 - 8.1 Actual-value-display
 - 8.2 Set point setting
 - 8.3 Regulation ratio display / manual operation
9. **Special functions**
 - 9.1 Self - optimisation
 - 9.2 Timer
 - 9.3 Program controller
 - 9.4 on / off function
 - 9.5 Operating hours and firmware version
10. **Error message**
11. **Contact load**
12. **Mounting plate/ Fastening**
13. **Disposal**



BA_E_HT40_Serie_v1.0.doc

1. Safety

This chapter provides important information about the safe operation of your HT40 and the use of these instructions.

1.1 Intended Usage

The HT40 series regulator is a microprocessor-based temperature regulator for industrial applications which has its own surface-mount housing. The configurable regulator is used to impose control, according to the parameters set, on manufacturer-approved heating elements (resistive loads) with defined sensors.

1.2 Non-intended usage

All usage outside the scope of those described in Point 1.1 are non-intended usage and may be hazardous and/or lead to consequential damage.

1.3 Operator

Installation, electrical connection, commissioning, operating and maintenance of the HT40 may only be performed by trained professionals who have been authorised or instructed for these activities by the operating authority.

1.4 Safety-relevant notices

Safety notices in this guide are marked by symbols. These notices are placed immediately before the procedure step to which they apply and must be followed precisely in order to avoid hazardous situations for persons and property damage to objects.

The following pictograms are used to call attention to notices:



Attention ! is used to call attention to potential health hazards or lethal situations.



Note ! is used for notices which, if disregarded, could result in failures during operational processes.



Tip ! is used to provide advice or additional information.

1.5 Liability exclusion

We herewith expressly serve notice that Hillesheim is not liable for any damage resulting from incorrect or negligent operation, maintenance or non-intended usage. This also applies to device modifications, attachments and conversions which could be detrimental to safety. In these cases the manufacturer's warranty is voided.

2. General

2.1 Unpacking and inspecting

The product must be inspected for possible shipping damage when it is unpacked. If damage is found then the freight carrier, railway company or postal authority is to be notified so that a damage report can be initiated.

2.2 Standards and regulations

This product complies with the following national and European regulations:



The "Electromagnetic compatibility" directive (89/336/EEC and 93/68/EEC)

The "Low voltage equipment" directive (73/23/EEC und 93/68/EEC)

3. Important reference before start up procedure



According to the EMV instructions 89/336/EEC this controller is only a part of a complete unit. After connecting a heating system this EMV-instruction insists a new EMV-test. We call your attention to the fact, that the start up person is obligated to meet these instructions.

This controller was suppressed after practice measurements, therefore during operation with resistive components / heatings there should be no EMV-fails.


In case of using an electrical heating or a heating in uncontrolled operation, we call your attention to the VDE-instructions (safety in electro-heat-units DIN EN 60619-2 [VDE 0721 part 411]) and the instructions from professional association, which demand a thermal supervision (or a thermal clipper) in this case or an own-safe architecture. Please ask company Hillesheim in these cases.

4. Introduction

The self-optimised controller is an universal controller for machine-, unit- and apparatus construction because of its free configuration, its serial interface and the special compact construction.

This operating manual should support you with start up and operation of the controller. If you start up a controller of the compact controller series for the first time, please read next chapter start up.

block diagram




All controller functions are comprehended in four levels for a more easy and clear handling.

Operating level: standard mode, if controller is active. Here, e.g. the set point can be set or the regulation ratio can be displayed.

parameter level: can be called up by p-key; here, e.g. the parameter records for P, I and D are stored to modify the controller for process.

Configuration level: can be called up by p-key together with a code word to set the basic logic function of the controller, e.g. controller mode, mode of action of the inputs and outputs.

Special level: can be called up by pressing two keys together to program or activate e.g. the program or the timer.



5. Start up

Check power supply on type plate!

What to do:

1. Check position of jumper clip for measure input (right cover side) page 4
2. Assembly and electrical terminal, set up power supply page 4
3. Select configuration level, fixing of controller configuration, measure inputs and controller outputs (not necessary if configured by manufacturer) page 6ff

4. Select parameter level, set control parameters X_p , T_v , T_n , etc. according to the process
5. Start operation (operating level) e.g. adjust setpoint

page 10

page 15

More writing options, please see list of contents

- 1 Connecting serial interface (option)
- 2 Measure input configuration

• thermocouple or resistance thermometer Pt100


• standard signal 0(4) ...20mA

• after switch clipper alarm function

- 3 Alter switch clipper alarm function

• temperature clipper (relay Y2: clipper-function)

• alarm function relay Y2



Assembly surface ca. 160,0mm x 100,0mm

5.1 Assembly



Please make sure that during assembly and following configuration of the controller the load-circuit is switched off. The controller should be assembled in such a way to protect it from inadmissible moisture and strong soiling. The admissible ambient temperature of 0...50°C may not be passed over, even under worst conditions.

1. Compare power supply on type plate with supply voltage.
2. Check position of the jumper clip for measure input, and only set it at standard signal to the left or right position.
3. The mounting occurs by the four drillings (Ø 4,2mm) at the edges of the cooling plate. The cover must not be opened. Use screw with a 4mm diameter, e.g. M4

A spatial separation between controller and any inductive user / circuit breaker has to be guaranteed.

5.2 Electrical terminal



Voltage-, actuators- and test probe terminals have to be effected according to the terminal diagram (page 5, contact load HT41 and 43 see p.22).

The electrical wires have to be installed according to the customary instructions, resp. the legal instructions (in Germany e.g. VDE 0100) The controller is built in protection class II acc. DIN 57411/ VDE 0411. A terminal of a grounding conductor is not necessary. There is an internal connection between the grounding conductor and the user.

The controller has to be used at a separate voltage-supply, at the connecting terminal there may not be installed any other control current circles (circuit breaker, fan, etc) directly; they have to be wired separately.

Use shielded wires and ground them one-sided.


To avoid noise crash on wires/control lines, the circuit breakers and magnet vents have to be suppressed with adjusted RC-links.

The function of the signal terminals depends to the specific configuration. By activating the clipper function, the load circuit (L) is leaded over output A2 (relay 16A). There is also signal output A3 available.


Configuration of the outputs HT40.....			
Configuration	triac output A1	relay output A2	relay output A3
☐ 0201	Y1: heating	Y2: alarm	Y3: alarm
☐ 0202	Y1: no function	Y2: heating	Y3: alarm
☐ 0203	Y1: heating	Y2: clipper function	Y3: alarm

5.3 Terminal diagram


signal inputs



power-/alarm outputs



standard setup



temperature clipper function

HT41 controller
HT42 controller
HT43/44/45 controller

wired completely with temp. clipper function, but free configuration*
clamp controller standard set-up, free configuration*
wired completely in standard set-up, setted (tracer type, array)

* carriage restore sensor type PT100, array 0...200°C, alarm output limit comparator +/- 10K


5.4 Operating elements and displays

Displays

- 1 deviation display (W-X)
- 2 digital display for actual-value / set point and datas
- 3 switch mode display of the controller outputs
- 9 temperature clipper attention display

Key functions

- 4 set point key [S]
- 5 parameter selection key [P]
- 6, 7 value smaller / bigger
- 8 reset key temp. clipper



Double key functions

- [S] [P] timer (Option) on / off pressing longer the programming function will be called up
- [P] [Δ] program on / off if pressing longer the programming function will be called up
- [Δ] [▽] adaption on / off
- [P] [▽] on / off function of controller outputs

Typography

- 9999 digital display of the set
- ** ** dummy for any display
- [P] k brief key stroke (ca. 0,5 s)
- [P] long key stroke (ca. 4 s)
- [P] very long key stroke (ca. 7 s)
- [P] keep key pressed
- [S] [▽] keys, pressed together
- 2x [P] keys, to be pressed twice
- ⌂* radix point blinking in segment display



Please make sure that during configuration of the controller the load-circuit is switched off!

6. Unit configuration



In the configuration level the controller will be modified to the control task and prepared for operation. The manufacturer configuration should be checked before the first start up and maybe changed.

The whole controller configuration is stored in a four-digit alpha-numeric code. The two most significant digits show the carriage restore. For each carriage restore a possible variant can be chosen (e.g. `000.**` =carriage restore "controller type", where the ** stand for variants `.02` =two-state-controller, `.03` = three-state-controller etc.) or a value can be set (e.g. `015.--` = actual-value-correction).

The basic procedure of a code selection / change is as follows:


1. select the code to be changed with `Δ` or `▽` (leaf)
2. release the selected code with `P` (radix point is blinking in P-display)
3. select variant or set value with `Δ` or `▽`
4. confirm the change / selection with `P` (radix point is not blinking anymore)

Mentioned below there is an example for a change of configuration described:

1. selection of the configuration level
2. change of a function / value
3. quit the configuration level


The configuration level is protected with a code word, which has to be typed if selected. From the manufacturer the code word is 1. If the code word is set wrong, the controller reverses into operation level (change of code word see page 18).

Selection of the configuration level:




Change of a function:

(Example: change code `00.**` from `0002` to `0003`)




change of a value:

(Example: change code `015.--` from `-230` to `500`)



Quit configuration level:



6.1 Configuration tablet

Mentioned below there are all configuration codes shown in a tablet. For more information's for functions please see the corresponding references. In the last column (✓) there are shown the manufacturer settings.

Function	Code	Variant / Range	
Controller selection reference p.9			
Controller type	0002	Two-state controller	✓
*= option	03	Three-state controller *	
	04	Three-state stepper controller *	
Configuration	0201	Regulation ratio Y1 triac → output A1 heating Y2 and 3 alarm	✓
Configuration	0202	Regulation ratio Y2 relay → output A2 heating Y3 alarm	
Configuration	0203	Regulation ratio Y1 triac → output A1/A2 Clipper function Y3 alarm	
Start function	0300	Direct start up	✓
	01	Start up with ramp	
Characteristic	0501	Falling (typ. Heating)	✓
	02	Rising (typ. Cooling)	
Measuring input reference p.9			
Input signal	001	Thermocouple / Resistance-thermometer	✓
	02	-20 ... 100mV	
	03	0 ... 10 V	
	04	0 ... 20 mA	
	05	4 ... 20 mA	
Function	Code	Variant / Range	
Unit	101	°C	✓
	02	°F	
	03	%	
	04	User-defined	
Linearization	1200	without -1999...9999°C	✓
	01	Pt 100 0...200°C	
	Array	Pt 100 -200...800°C	
	02	Ni 100 -60...180°C	
	10	Fe-CuNi, L -200...800°C	
	11	Fe-CuNi, J -200...1100°C	
	12	NiCr-Ni, K -200...1300°C	
	13	PtRh-Pt, S 0...1760°C	
	14	PtRh-Pt, R 0...1760°C	
	15	PtRh-Pt, B 0...1820°C	
	16	Cu-CuNi, T -200...400°C	
	17	Cu-CuNi, U -200...600°C	
Referencejunction - compensation	1400	off	✓
	01	on	
Actual-value correction	15--	-500...500	0
Scale standardsignal	18-- 19--	-1999...9999 down	-200
	-	-1999...9999 up	800
Function	Code	Variant / Range	
Set points reference p.10			
Set point clipper	32--	-1999...9999 down	-200
	33--	-1999...9999 up	800
Set point	34--	-1999...9999	0
Three-state controller (option)			

Motor minimum cyclic duration factor	└ 4 00 1	50msec	✓
	02	100msec	
	03	200msec	
	04	300msec	
	05	400msec	
	06	500msec	
	07	700msec	
	08	900msec	
Motor run duration	└ 42.--	0 ... 250 s	00
display settings reference p.10			
Fractional digits (standard-signal)	└ 0 00	0 Fractional digits	✓
	01	1 Fractional digits	
	02	2 Fractional digits	
	03	3 Fractional digits	
Function	Code	Variant / Range	
User guide	└ 00 1	German	✓
	02	English	
Alarm output Y2 (clipper function) reference p. 10			
Start up-alarm	└ 2000	off	✓
Suppression	01	on	
Function	└ 2 00	without	✓
	01	Signal contact	
	02	Limit comparator	
	03	Boundary contact	
	04	Signal contact (invers)	
	05	Limit comparator (invers)	
Hysteresis	└ 20 1	0,1 %	✓
	02	0,3 %	
	03	1,0 %	
	04	3,0 %	
Alarm output Y3 reference p. 10			
Start up-alarm	└ 2000	off	✓
Suppression	01	on	
Function	└ 2 00	without	✓
	01	Signal contact	
	02	Limit comparator	
	03	Boundary contact	
	04	Signal contact (invers)	
	05	Limit comparator (invers)	
	06	Boundary contact (invers)	
	07	Segment-end-contact	
Hysteresis	└ 20 1	0,1 %	✓
	02	0,3 %	
	03	1,0 %	
	04	3,0 %	
Lag	└ 23.--	0 ... 500 s	0
Locking	└ 2400	off	✓
	01	on	
Reset code	└ 25.--	1 ... 255	111
Protection against unauthorised operation reference p. 10			
Code word	└ 00.--	1 ... 255	
Set point	└ 0 00	disabled	✓
	01	enabled	
Alarm values	└ 0200	disabled	✓
	01	enabled	
Control parameters	└ 0300	disabled	✓
	01	enabled	

Manual operation	£ P4.00 01	disabled enabled	✓
Program	£ P5.00 01	disabled enabled	✓
Serial interface	£ P6.00 01	disabled enabled	✓
Function	Code	Variant / Range	
Serial interface reference p. 12			
Baud rate	£ U1.01 02 03 04 05 06	300 Baud 1200 Baud 2400 Baud 4800 Baud 9600 Baud 19200 Baud	✓
Set address	£ U2.-- 0 ... 253		0

6.2 Controller selection

Configuration code

£00.** to £05.**

The controller can be configured as two-state-, three-state- or three-state-step-controller (£00.**).

The regulation ratio output of the controller can be rerouted via change-function from output A1 (relay) to output A3 (logic) to trigger e.g. semiconductor-relays directly.

The **start-function** (£03.**) decides if the set point or the program should be started after switch on or reset the controller (see chapter 6.3, p.33).

The **characteristics** (£05.**) describes the behaviour of the controller after changing the actual-value. If the actual-value is below set point, then a falling characteristics means a rising of the regulation ratio Y1 (typ. heating). But a rising characteristics means a decrement of the regulation ratio Y1 (typ. cooling).

Two-state controller

Two-state-controller with triac output and two signal relays (Code £0201) or as

Two-state-controller with relay output and one signal relay (Code £0202) or as

Two-state-controller with triac output / clipper function and one alarm relay (Code £0203).

6.3 Inputs

Configuration code

£10.** and £13.--

At the measuring input there can be aligned different sensors or test probes (see p.5 terminal diagram). With the parameter code "input signal" (£10.**) the type of the emitter can be fixed. For the different thermometers there are linearization-tablets (£12.**) in the controller. These proceed the translation of the dates to the real temperature. If such a sensor (£12.**) is chosen, the additional scale (£13.--, £13.--) is not active.

The measure signal (=actual-value) can be corrected / scaled in different ways.

Without correction:

The reference junction compensation (£14.00) is switched off, the actual-value-correction (£15.--) is set to 0 and the scales (£13.--, £13.--) are adjusted to the range limits of the emitter.

Reference junction compensation (only active at thermocouple):

The reference junction compensation (£14.01) is switched on, the actual-value-correction (£15.--) is set to 0 and the scales (£13.--, £13.--) are adjusted to the range limits of the emitter.

AI-value-correction: (£15.**)

The actual-value display of the controller can be corrected in range ± 500 (sensor alignment) (reference: at Pt100-dual-conductor-mode the actual-value will be shown too high without correction, if the lines are longer).

Scale with standard signals:

With the parameters scale standard signal down and up (£13.--, £13.--) any modification of the actual-value display to the date is possible. If there e.g. is a norm signal emitter 0..10V connected, which shows a date from 250°C (=0V) to 550°C (=10V), then the display can be modified setting the lower scale value (£13.--) to 250 and the upper (£13.--) to 550.

If the unit of the actual-value (£11.**) is set to °F, each values will be converted from °C to °F.

6.4 Outputs

Control output Y1 / A1

The switch output Y1 / A1 is always used as a two-state output of the regulation ratio. For switch element there is an electronic switch (triac) used. You have to make sure always to switch a phase (L1, L2, L3) over this contact.

Control- / alarm output Y2 / A2

Configuration code

££ £.** to £££.**

Depending on the configuration the switch output Y2 / A2 is used as an alarm output or, if thermal clipper coded, as permanent switch off.

Alarm output Y3 / A3

Configuration code

££ £.** to £££.**

The switch output Y3 / A3 is always an alarm output and can be configured additionally with an alarm lag (£££.--) and a locking (£££.--). If a locking was activated it has to be reset with a code word (cd5.--) in the user level (£££.--) in the user level.

6.5 Set points

Internal set points

Configuration code

£££.** to £££.--

For the set point a value can be set in the configuration level (£££.--). By changing the set point with keyboard it will be stored. A clipping of the set point input is possible (£££.-- and £££.--).

6.6 Adjustments of the display

Radix point and user interface

Configuration code

££ £.** and £££.**

The radix point (££ £.***) can be chosen free depending on the used sensor or test probe. If a special thermometer is chosen, only a display without or with one fractional digit is possible. The user interface can be read in german (£££££) or in english (£££££).

6.7 Protection against trespassed operation

Configuration code

£££.-- to £££.**

Some operation functions can be protected against trespassed operation (££ £.***, £££.**), the configuration level is protected with a code word (£££.--) as well.

6.8 Serial interface (Option)

Configuration code

££ £.** and £££.--

If there is a serial interface RS232 used, the baud rate (££ £.***) and the set address (£££.--) has to be adjusted.







7. Parameter level

For adjustment of the controller to the current controlled system, in the parameter level the values for P, I, D, cycle time etc. are stored.

The manufacturer adjustments have to be checked and maybe changed.


If you don't know the motion control you should determinate the parameters with self-optimisation (page 16) and reset the control-action results according to behaviour with optimisation references (page 14).

The basically procedure of the parameter input is as follows:

1. choose the parameter level with  in the operation level (standard operation) (P-P-R will be shown for control)
2. change parameters with  or  or
3. choose, change, etc. the next parameter with  and  return to operation level (b££££) with 


According to the configuration in the parameter level only relevant parameters will be shown! (b££££) is shown.

Selection of the parameter level:




Change of a value:

(expl: change parameter p-share from 5.0 to 5.0)



Quit the parameter level:



The set switches automatically to the operation level if there is no key pressed within 25s.

Parameter tablet



Following all parameters are shown in a tablet. For more information about functions please see according references. According to the controller configuration in the display only relevant parameters will be shown. Cooling parameters are signed through a radix point. In the last column of the tablet the (✓) manufacturer settings are shown.

Parameter		Value range	
Two -state/heating			
P-share X_p	P	0.0 ... 500 %	0.5
I-share T_n	I	0.5, 1 ... 4000 sec.	50
D-share T_v	d	0.5, 1 ... 1000 sec.	11
Switch hysteresis h_y	h	0.1%; 0.3%, 10%, 30%	10
Switch cycle time T	c	10 ... 100 sec.	10
Cyclic duration factor Clipper min.	z	0, 5, 10 ... 50 %	0
Cyclic duration factor Clipper max.	z	50, 55, 60 ... 100 %	100
Others			
Detector breaking	F	bei Zweipunkt-Regler 0.5, 0 ... 100 % bei Dreipunkt-Regler - 100 ... - 1, 0.5, 0 ... 100 %	0
Switchpoint lag	-	0 ... 125 (Dreipunkt) 0 ... 125 (3P-Schritt)	0
Parameter		Value range	
Alarm values			
Alarm values 1	*	value range of Sensor	0
Alarm values 2	*	value range of Sensor	0

*= symbol depends on configured

Reference to parameters



p-share (X_p): is adjustable from 0,1...500% and accords to the current measuring range, i.e. with Pt100 (-200...+800°C) 1% X_p corresponds to a value:

$$\frac{1\% \cdot 1000^\circ \text{C}}{100\%} = 10^\circ \text{C}$$

but with NiCr-Ni (-200...+1300°C):

$$\frac{1\% \cdot 1500^\circ \text{C}}{100\%} = 15^\circ \text{C}$$

So the X_p should be reduced to 0,7% with NiCr-Ni-sensors to get the same control-action result. (Also important at X_p - takeover from external brands!)

At a X_p -adjustment of 0.0 the structure is switched to an on/off behaviour, i. e. the control output Y1 can be used e.g. as MIN-contact.

I-share (T_0): the range is adjustable from 1...4000 sec. The parameter adjustment RUS is used for structure shift.

D-share (T_v): the range is adjustable from 1...1000 sec. The adjustment RUS is used for structure shift.

Switch hysteresis (h_v): has an effect on control output Y1 only by on/off structure.

Cyclic duration factor limitations: specifies at which regulation ratio a regulation ratio output occur. All regulation ratios below the minimum cyclic duration factor limitation will not be given to the current control output (Expl.: short turn on of a cooling compressor can be avoided.). All regulation ratios above the maximum cyclic duration factor limitation will be limited to this value.

sensor breakage behaviour: states, which regulation ratio will be shown at the control output if sensor breakage occurs. Manufacturers adjustment: 0%. This parameter can be set to RUS at the two-state- and three-state-controller. This possibility make the controller work on with the last regulation ratio if sensor breakage occurs.

Switching point distance: works as a "dead zone" between control outputs Y1 and Y2, so that both outputs can't be switched at the same time. In this "dead zone" none of both outputs Y1 and Y2 are switched on.

Structure shift

The controller has a structure shiftable control algorithm. The control behaviour on/off, P, PI, PD or PID is selected according to the following tablet, and not relevant parameters will be set to RUS .

Controller structure	Proportional range X_p	Reset time T_N (I)	Rate time T_v (D)	Switch-hysteresis h_v	Switch cyclic time T
on/off	00	---	---	0.1-5	---
P	0.1-500	RUS	RUS	---	10-100
PI	0.1-500	1-4000	RUS	---	10-100
PD	0.1-500	RUS	1-1000	---	10-100
PID	0.1-500	1-4000	1-1000	---	10-100

Alarm values

The alarm values are limit values, at which the controller set the alarm, i.e. set the according switch output. The type of the alarm contact and its hysteresis depends on the configuration. In the parameter level the limit value (alarm value) is set. The display, which alarm is set, is shown in the parameter- resp. switch-mode-display.

Function		Comment
Signal contact	S	
Limit comparator	L	
Limit contact	δ	
Signal contact (invers)	S.	
Limit comparator (invers)	L.	
Limit contact (invers)	δ.	
Locking	ℓ	only Y3 code word for locking (0 ... 255)

In succession with the alarm function the according control port Y2/Y3 is blinking in the switch mode display!

If an alarm function is switched off, the according alarm value is not shown!

Y2 can only be used as an alarm contact at the two-state controllers (standard adjustment clipper function switched off)!

If the locker of Y3-alarm is activated (symbolised by blinking in the switch mode display), the locker can be reset with a code word. In the parameter display a ℓ will be shown instead of the alarm function (cf. tablet 4.3). The reset code can be adjusted with ∇ - and Δ - keys and confirmed with P --key. It is adjusted to 111 from the manufacturer.

References to the alarm functions

Signal contacts are used to supervise the positive and negative control deviation. The alarm value will be set as distance to set point and is linked to its dissimulation. The switch output is closed (positive), if the actual-value is below the adjusted value, above switch threshold it will be opened (high resistance). This behaviour can be inverted (invers).

Limit comparators enable the supervision of a symmetric good range around the set point. The limit comparator switch point is linked to the set point analogue to the signal contact, and will be set as distance to it. Inside the good range the switch output is closed (positive), outside it will be opened (high resistance). This behaviour can be inverted (invers).

Limit contacts will be adjusted to a fixed value inside a measuring range, independent from the set point. If the actual-value is below the adjusted value, the switch output is closed (positive), if the actual-value rises above this value, the contact opens (high resistance). This behaviour can also be inverted (invers).

If the start-up-alarm-suppression is switched on, an alarm is suppressed while start-up the stage until the actual-value for the first time moved into the alarm-good range. The alarm-good range corresponds to the alarm mode at actual-value = set point. After that the behaviour corresponds to the configured alarm function.

The program-end-alarmcontact Y3 will be confirmed by pressing [P]--key.

Adjustment effects of the parameters

Two-state/three-state controller			
Characteristic value	Adjustment	control proceedings and compensation of malfunctions	start-up proceeding
P (X_p)	larger	more subdued, slower compensation of malfunctions	slower reset of regulation ratio Y, perhaps overshoot
	smaller	less subdued, faster compensation of malfunctions; at oscillating control size: enlarge P	faster reset of regulation ratio Y; at oscillating initial run to the set point:: enlarge P
I (T_n)	larger	more subdued, slower compensation of malfunctions	slower change of regulation ratio Y
	smaller	less subdued, faster compensation of malfunctions; if stability too small: enlarge X_p	faster change of regulation ratio Y
D (T_v)	larger	less subdued, more reaction to malfunctions	earlier switch off before set point, perhaps creep to the Set point
	smaller	more subdued, less reaction to malfunctions	later switch off before set point, perhaps overshoot

8. Controller handling



In the closed-loop control the set is in the operation level. A change into the operation level is shown with a short display $bEdn$. In the operation level you can move with the [P]--key through the different operation functions. The according values can be changed with [V]- and [A]-key.

The set point will be shown by pressing the [S]-key and can be changed by keeping the [S]-key pressed and pressing the [V] or [A] keys (a change from actual-value- to set point-display will be confirmed with a short reverse clipping of the actual-value).

Some operation functions can be protected against trespassed operation!

During display of actual-value, set point, regulation ratio or deviation, there are shown the modes of the three switch outputs in the parameter display.

If there are 3 dots (...) in combination with blinking timer display, RUS or a r' -symbol shown in the actual-value/set point display, then there is a special function active.

Display of the operation level

P	P alternated	Display	Function
≡		3000*	Set point and set point dissimulation
≡		3000*	Normal position Actual-value display
≡		y 80*	Regulation ratio display/ manual operation 0(-100)...100%
		$bEdn$	Change into normal position (display approx. 2s)

* The display always shows the actual value

8.1 Actual-value-display

The actual-value-display is the standard setting of the operation level. It is shown every time after display $bEdn$, when a change into the operation level was effected. The deviation to the set point is shown on a bar display within range -9...0...+9. If deviations are larger than $\pm 12^\circ\text{C}$, the according LED is blinking.

Change into the actual-value display:

		$n \times [P]$	Operation level: press [P] several times until $bEdn$ is shown.
		↓	
	$bEdn$		$bEdn$ is shown. Display changes after approx. 2s
		↓	
≡	3000		Actual-value-display (standard setting)

If there is F_{min} , F_{max} or F_{PaL} shown in the actual-value-/set point-display, then a sensor breakage or an overflow of the sensor occurred (cf. chapter 6.3)

If the actual-value-/set point-display is blinking, then a range overflow of the measuring signal occurred!

8.2 Set point setting

In the operation level the set point can be set with key \boxed{S} and $\boxed{\nabla}$ or $\boxed{\Delta}$ together within the configured set point limits (cf. chapter 3.5, p.18). The controller is working with the new value after a set point reset and stores it in an EEprom, so that it will be kept after a power disconnection.

Only internal set points can be adjusted by keyboard!

Change of the set point:

(Expl.: change set point from 300.0 to 350.0)

≡	300.0	\boxed{S}	Actual-value-display: keep \boxed{S} pressed – set point-display
		↓	
≡	350.0	$\boxed{S} \boxed{\Delta}$	Change set point: press \boxed{S} and $\boxed{\Delta}$ until new value reached
		↓	
≡	350.0	\boxed{S}	Let go $\boxed{\Delta}$: new set point is shown
		↓	
≡	300.0		Leave \boxed{S} : back to actual-value-display

8.3 Regulation ratio display / manual operation

In the display there is a Y placed in front of the regulation ratio. During manual operation the y will be replaced by a H. The value range of the regulation ratio depends on the type of controller. It extends from max. - 00% resp. 0% 00%.

Change into the regulation ratio display:

≡	300.0	1 x \boxed{P}	Set point display (standard setting): press \boxed{P} 1x
		↓	
≡	y 80		Regulation ratio is shown

If you want to change into manual operation, i.e. set a regulation ratio manual, you can use the $\boxed{\nabla}$ or $\boxed{\Delta}$ -keys in the regulation ratio display. The controller changes from closed-loop control to manual operation. During manual operation there is no controlling. The chosen regulation ratio will be put out directly on the switching output!

A cyclic duration factor limitation of the regulation ratio has no influence on the manual operation!

Change of the regulation ratio (manual operation):

(Expl.: change regulation ratio from 80% to 50%)

≡	y 80	$\boxed{\nabla}$	Regulation ratio display: press $\boxed{\nabla}$
		↓	
≡	H 80	$\boxed{\nabla}$	Manual operation: press and keep pressed $\boxed{\nabla}$ until value reached
		↓	
≡	H 50		Manual operation: new regulation ratio

Back to regulation ratio display:

≡	H 50	\boxed{P}	Manual operation: press \boxed{P}
		↓	Regulation
≡	y 80		ratio will be displayed.

Back to actual-value display:

≡	y 50	\boxed{P}	Press \boxed{P}
		↓	
≡	650.0		650.0 will be displayed. Display changes after approx. 2 s to actual-value display.

9. Special functions

The units of compact controller series are equipped with a number of special functions. These are self-optimisation, timer function and program controller. Basically they can be reached by pressing two keys in the operation level. On the front foil of the controller there are the symbols for these functions at the corresponding key-combinations.

9.1 Self-optimisation

As standard the controller is equipped with a self-optimisation-algorithm and is able to calculate the control parameter either during start up the controlled system or on demand.


As base for optimization procedure there are modified adjustment rules by "Ziegler und Nichols". At the calculation method the controller will be optimized to the response to setpoint changes and the procedure is practicable for controlled systems with equalization and not dominated dead time ($T_u : t_g \leq 0.2$).

During the self –optimisation the controller calculates the parameters $P (X_p)$, $I (T_n)$, $D (T_v)$ and the cycle time for both the two-state-controller and three-state-controller.


The self-optimisation only starts at a stable actual-value! The program controller and the timer have to be switched off.

Self-optimization during start up of the controlled system

(Expl. Optimize controller to 300.0) switch off controlling (switch outputs):




Adjust the aimed set point within these 2 s:




5 s after last key stroke the controller starts the self-optimisation. For control, the **OPB** is blinking in exchange with actual-value in the display until the optimisation is finished or interrupted.

Self-optimisation during controlling

(Expl. Optimise controller to 350.0)




Adjust the aimed set point within these 2 s:



5 s after last key stroke the controller starts the self-optimisation. Therefore the controller reduces the actual-value independently to a determined value. For control, the **OPB** is blinking in exchange with actual-value in the display until the optimisation is finished or interrupted.

Interrupt of self-optimisation



After finished optimisation the determined parameters will be stored in the parameter level. The controller automatically works with these values. The control parameter can be shown in the parameter level and eventually modified manual (cf. chapter 7)

After 2 h not finding any control parameters, the controller interrupts the optimisation with an error message F-2!

9.2 Timer

The timer enables a time-controlled switch On and Off of the controller.


Timer programming

The timer can be programmed with a switch time and a switch function (cf. tablet 6.1). The switch time specifies the period from starting the timer until execution of switch function.

Display	Function
001 ... 9999	Switch time 1 min to 100h
RU5	Switch function OFF: controlling is switched off (Standby)
E n	Switch function ON: controlling is switched on


If the controlling is switched off (standby) during timer operation, this will be symbolised with 3 dots (...) in the display. The clock symbol at the front is blinking. The standby mode will be interrupted by pressing any key!

Change to the timer programming:




Adjust switch time:

(Expl: change switch time from 1 min to 10 h)




Just switch function:

(Expl.: change switch function from RU5 to E n)




Leave timer programming:



Start and Stop of the timer


The timer will be started / stopped from the operation level. If it is active, the clock symbol at the front is blinking. The timer can't be started while self-optimisation, program controller- and manual operation.

If the controlling is switched off during timer operation (Standby), this will be symbolised with 3 dots (...) in the display. The standby mode will be stopped by pressing any key.



9.3 Program controller

The program controller enables a program-controlled start of the set point for a fixed time. The program has 6 segments with 6 set points and 6 segment times. The program can be started and stopped with the keyboard. Also, a stepping of the program segments is possible with the keyboard. The figure 6.1 shows a possible curve of the program:



A segment- resp. program stop can be marked at alarm output Y3!


T₁ will get shorter, if the actual-value is bigger than the reference temperature of 20°C at the program start.

Programming function

Each of the 6 program segments can be related one set point and one segment time. Which segment is active, can be displayed with the symbol **~** and the exchange blinking segment number (1 to 6). First the set point and then the time of the segment will be displayed resp. changed.

The segment time is adjustable from 1 min to 100 h. If it is set to **EndE**, the program runs until before the corresponding segment.

Change to the programming function:



Adjust segment set point:

(Expl. Change of set point 1 segment from 0.0 to 300.0)

0.0		Set point 1: press and keep pressed until new value reached
300.0		Confirm new set point: press
EndE		Segment time will be displayed

Adjust segment time:

(Expl. Change time of 1. segment from EndE to 5h)

EndE		Segment time: press and keep pressed until new value reached
5.00		Confirm new time: press
0.0		Set point of the next segment will be displayed

All following segments have to be adjusted in the same way!

Quit programming function:

0.0		Segment set point: press longer than 3 s
bEdn		bEdn will be displayed briefly
300.0		Operation level: actual-value will be displayed

Start and stop of the program

The program can be started and stopped from the operation level. If the program is active, the actual program segment and the actual-value will be displayed in the actual-value-display in exchange.

Program starting with keyboard:

300.0		Operation level: press and briefly
Start		Start will be displayed briefly
;		Program: actual segment will be displayed

If the self-optimisation or the timer are active, the program can't be started.

Program stopping with keyboard:

;		Program: press and together
Stop		Stop will be displayed briefly
300.0		Operation level: actual-value will be displayed.


If the segment time of the 1. segment is set to EndE, the program can't be started. There will be an error message F-3 (cf. chapter 10)! If the actual-value is bigger than the first program set point, the program can't be started.

The program-end-alarm contact can be confirmed by pressing .

Stepping – program segments

If the program is active, you can step from the actual program segment to the next segment with the keyboard. If you step from the last program segment, the controller stop the program execution.


Stepping of the program:




9.4 on/off function

The units of the compact controller series can be switched on and off with the double key function of [P] and [V]. If the controller is switched off, there is the symbol *RUS* in exchange with actual-value. In this mode all outputs and the controlling are switched off. Only the actual-value will be determined and displayed.

Switch off the controller:



Switch on the controller:




The on/off mode will be stored during a power interrupt and ensuing it will be active again!

9.5 Operating hours and firmware version

The controller is equipped with a meter panel which will be actualised hourly and be stored in the non-volatile store (EEPROM). If you are in the configuration level, you can have a look at the meter panel. Also, there you can readout the firmware version of the controller. By having any technical demands you have to state this version number.

Display of the operating hours:


(Expl. 2178 operating hours) Chose configuration level (see chapter 6)!



Display of the firmware-version:

(Expl. Version number F1.01)

Chose configuration level! Chose configuration code *U2*! --



10. Error message

Error messages will be displayed in the display of the controller with a *F* and following number or with a corresponding symbol. The error messages with error numbers can be erased by briefly pressing [P] (except error -1).

F---- or *F----*

Description:

At the measuring input or at the external set point input there is a sensor breakage, a sensor short circuit or an overflow of the test probe.

What to do:

If this error is shown instead of the actual-value, check the connected sensor to sensor breakage and check the electrical connection. Check the configuration of the measuring input.

F Pol

Description:

At the measuring input there is a polarity of sensor of the connected thermocouple.

What to do:

If this error is shown instead of the actual-value, check the connected sensor to polarity of sensor. Check the configuration of the measuring input.

F -3

Description:

Time of 1. segment is adjusted to EndE. The program doesn't start.

What to do:

Confirm error with key [P]. check set point and times of start-up ramp.

F -2

Description:

During the self-optimisation there is a time overflow. No control parameters could be found.

What to do:

Confirm this error with key [P]. check the sensor connection and the connection of the actuator, pay attention to the unit configuration. Check the actual-value and the set point and make sure, that before starting the optimisation the actual-value was below the aimed set point and was stable.

If all described errors are excluded there is a manual adjustment of the parameters necessary.

F -1

Description:

An error happened in the non-volatile store (EEPROM).


What to do:

This error can't be removed by the user. Please send the unit to your distributor.


11. Contact load

Flange box 6+PE, max. 10A (binder series 693 ...)

HT43



HT42




Clamp connection see the connection diagram on page 5. Cable run only through the planned PG-screwings, 2x PG9 for power / heating, 2x PG7 for sensors and signals.

For connecting the self-holding clamps a screwdriver has to be set into the square opening of the clamp and this opens the clamp by slight levering. After removing the screwdriver blade this connection is closed. This clamp type is only to be used at one wire!

HT45


Flange box 4+PE, max. 20A (binder series 694 ...)



Ansicht auf die Lötanschlüsse der Steckereinsätze
View on termination side of male inserts


Kontakte/contact Stecker/plug - 6+PE	PT100 2-Leiter	Fe-CuNi (J)	NiCr-Ni (K)
1 Phase phase	braun brown	braun brown	braun brown
2 Nulleiter neutral wire	blau blue	blau blue	blau blue
3 Temperaturfühler temperature feeler	rot (schwarz) red (black)	+ schwarz black	+ grün green
4 Temperaturfühler temperature feeler	weiss (schwarz) white (black)	— weiss white	— weiss white
PE Schutzleiter protection earth wire	grün/gelb green/yellow	grün/gelb green/yellow	grün/gelb green/yellow

HT41




HT44

HT44 --> 230/400V AC 3 x 10A



Flange box 8+PE. max. 16A (HANQ8)

12. Mounting plate / Fastening



Special devices:

Three-channel regulator, HTM41 and 42 (3xHT42)
Mains connection terminals 230/400 V AC
5 pole terminal block (L1/L2/L3/N/PE)
Load connection terminals, 16 A maximum
9 pole terminal block

H1(2/3)	=	heater phase legs
N	=	neutral conductor, heater
PE	=	protective earth,
heater		
G	=	ground (thermal
element/PT100 -)		
+	=	thermal element +
PT	=	PT100 (between G
and PT)		
W	=	PT100 monitor
W	=	PT100 monitor

Functions as described for HT42 regulator with limit function.

HT44 and HT55

Mounting plate 180mm otherwise as sketch

13. Disposal

Packaging

Materials used to package the device for transport are to be disposed of in an environmentally-friendly manner by giving them to the appropriate local disposal facilities.

Device components

Defective components are to be collected and disposed according to applicable regulations. The same applies to the device itself.